

HotBox Mounting kit

Contents

- 4x M3.5 x 16mm Machine screws.
- 4x Steel mounting plates.
- 4x No6 Self-tapping screws.



Fitting instructions

1. Using a No.2 Pozidrive screwdriver remove one of the screws on the base of the HotBox. Save this screw in case you decide to take the mounting plates back off in future.

2. Attach one of the steel mounting plates using one of the supplied M3.5 x16mm machine screws.
3. Repeat this for each of the three other corners.
4. Use the supplied No6 self-tapping screws to mount your HotBox to any wood or metal surface. If you find it difficult to screw into the surface try making a small pilot hole first.

